



Liberta Prima

3D Software for Timber Roofs and Structures



WETO Starter Software (for starting up WETO software)

Create your roofs quickly and easily with a wide range of functions

Quick and easy creation of basic trusses with the integrated Easy Wizard 'Roof Assistant'
Assistants for Dormers, Skylights, Chimneys and Eaves Projections with self-adaptation of Roof Framework
Designed to work EASILY and DIRECTLY in 3D and 2D!

Full 3D and 2D display of building design

Automatic wall fitting under the roof

3D inspector for machining of individual components

Automatic Hip/Valley Rafters + Careful placement of rafters with auto-adaptive or forced Interaxis



Other functions included:

Windows & Doors Editor | Controlled cuts | Carpentry lists

Automatic Technical Drawings of Roof Profiles | Several Views (Floorplan, ...) | AutoCAD Import/Export

Its ease of use and practicality make it the perfect tool for entering the world of Holzbau (timber construction)!



WETO AG
Muth 2
D-94104 Tittling

Tel.: +49 (0) 8504 9229-0
E-Mail: info@weto.de
www.weto.de

Send the order form to: info@weto.de

Liberta Prima only 100,00 €

Company: _____ Full Name: _____

Address: _____ Phone: _____

ZIP: _____ Location: _____

Date & Signature of holder: _____

Important Info:

*Prices are without VAT and are valid subject to revocation, price changes, general or printing errors.

The undersigned expressly accepts the terms and conditions of sale of WETO AG which can be found at www.weto.de

Within the scope of the business relationship management, the data of the customer are electronically processed. WETO will adhere to the legal regulations regarding data protection during the storage, processing and use of personal data.

The software requires Windows 10 or 11.



Liberta Prima

3D Software for Timber Roofs and Structures

FEATURES BY CATEGORY

Price: 100,00 € net

ROOF

Roof Assistant (Wizard)

Chimney editor (auto-framing on the opening)

Roof Window editor (auto-framing on the opening)

Dormer Assistant (Wizard)

Hip and Valley rafters editor

Rafters placement with Auto-Adaptive or Forced Interaxes

WALL

Single-layer walls (massive)

Automatic cut adjustment of the walls under the roof

Openings (windows and doors)

MACHINING OF COMPONENTS

Controlled cutting of components on existing references

Break/Split components (e.g. for load distribution)

OUTPUT

Wood List for Carpenters (timber, lengths, sections, areas and volumes)

Automatic Technical Drawings of Roof Profiles

Automatic Top and Elevation Views

Dimensions and Measurements

View/Inspect individual components and own machining processes

OTHER

Display of existing CNC Numbers in 2D and 3D

Searching for components by CNC Number

Selection of components by material and volumetric area